


FOGGERS LOC

Spare Parts Diagram



























LOC PART LIST

Dia No	Code	Part Description
101	SPAF-000300-AS2010101	AS2010101 (Casing 1)
102	SPAF-000300-AS2010102	AS2010102 (Casing 2)
103	SPAF-000300-AS2010103	AS2010103 (Truss Bolt 1)
104	SPAF-000300-AS2010104	AS2010104 (Truss Bolt 2)
105	SPAF-000300-AS2010105	AS2010105 (Nut)
201	SPAF-000300-AS2010201	AS2010201 (Chemical Tank)
202	SPAF-000300-AS2010202	AS2010202 (Chemical Tank Cap)
204	SPAF-000300-AS2010204A	AS2010204A (Cooling Water Tank)
301	SPAF-000300-AS2010301	AS2010301 (Check Valve)
301	SPAF-000300-AS2010301A	AS2010301A (Check Valve Set)
302	SPAF-000300-AS2010302	AS2010302 (Loc Pump Cylinder)
303	SPAF-000300-AS2010303	AS2010303 (Hex Nut) same as AS2010604
304	SPAF-000300-AS2010304	AS2010304 (Check Valve Pin)
305	SPAF-000300-AS2010305	AS2010305 (O Ring)
309	SPAF-000300-AS2010309	AS2010309 (Ranch Bolt)
310	SPAF-000300-AS2010310	AS2010310 (Truss Bolt 3)
402	SPAF-000300-AS2010402	AS2010402 (Loc O Ring)
405	SPAF-000300-AS2010405	AS2010405 (One Torch)
406	SPAF-000300-AS2010406	AS2010406 (Water Hood Check Valve) 407,408
409	SPAF-000300-AS2010409	AS2010409 (Water Hood Joint Hose)
410	SPAF-000300-AS2010410	AS2010410 (Water Hood Joint A/y)
501	SPAF-000300-AS2010501	AS2010501 (Pump Piston 1)
502	SPAF-000300-AS2010502	AS2010502 (Waring)
503	SPAF-000300-AS2010503	AS2010503 (Pump Piston Ball 1)
504	SPAF-000300-AS2010504	AS2010504 (Pump Piston Ball 2) refer part 605
505	SPAF-000300-AS2010505	AS2010505 (Cylinder)
506	SPAF-000300-AS2010506	AS2010506 (Pumping Rod)
507	SPAF-000300-AS2010507	AS2010507 (Pump Lever)
508	SPAF-000300-AS2010508	AS2010508 (Pumping Rod Spring Guide)
509	SPAF-000300-AS2010509	AS2010509 (Pumping Rod 2)
510	SPAF-000300-AS2010510	AS2010510 (Pumping Rod 3)
511	SPAF-000300-AS2010511	AS2010511 (Pumping Spring)
512	SPAF-000300-AS2010512	AS2010512 (Plan Washer)
513	SPAF-000300-AS2010513	AS2010513 (Packing)
601	SPAF-000300-AS2010601	AS2010601 (Coil)
602	SPAF-000300-AS2010602	AS2010602 (Injection Nozzle)
603	SPAF-000300-AS2010603	AS2010603 (Change Check Valve)
604	SPAF-000300-AS2010604	AS2010604 (Hex Nut)
605	SPAF-000300-AS2010605	AS2010605 (Ball)
606	SPAF-000300-AS2010606	AS2010606 (Swivel Ring)
607	SPAF-000300-AS2010607	AS2010607 (Check Valve Connect Pipe)
608	SPAF-000300-AS2010608	AS2010608 (Coil Protection)
610	SPAF-000300-AS2010610	AS2010610 (Bolt)
613	SPAF-000300-AS2010613	AS2010613 (Lighter Ceramic Clip)
614	SPAF-000300-AS2010614	AS2010614 (Lighter Ceremaic Screw)
615	SPAF-000300-AS2010615	AS2010615 (Lighter Ceramic Part)
701	SPAF-000300-AS2010701N	AS2010701N (Gas Body)
708	SPAF-000300-AS2010708	AS2010708 (Gas Pipe)
709	SPAF-000300-AS2010709	AS2010709 (GAS FILTER) 710
711	SPAF-000300-AS2010711	AS2010711 (Burner)
712	SPAF-000300-AS2010712	AS2010712 (Burner Net)
715	SPAF-000300-AS2010715	AS2010715 (Gas Screw)
717	SPAF-000300-AS2010717	AS2010717 (Orange Knob)
718	SPAF-000300-AS2010718	AS2010718 (Gas Control Valve Screw)
719	SPAF-000300-AS2010719	AS2010719 (Gas Body O Ring)
720	SPAF-000300-AS2010720	AS2010720 (Gas Can Lock Plastic (Black))
800	SPAF-000300-AS2010800	AS2010800 (Light Switch Assembly)
801	SPAF-000300-AS2010801A	AS2010801A (Light Switch Spring)
905	SPAF-000300-Belt	Loc Belt
	SPAF-000300-Leaflet	Loc Handy Fogging Machine Leaflet

FOGGERS INDIA P. LTD.

LOC HANDY FOGGING MACHINE

SPARE PARTS MASTER INFORMATION

 AS2010101 25 11500H	 AS2010102 25 11500H	 AS2010103 25 11500H
 AS2010104 25 11500H	 AS2010105 25 11500H	 AS2010201 25 11500H
 AS2010202 25 12300H	 AS2010204 25 11500H	 AS2010301 25 11500H
 AS2010303 25 11500H	 AS2010304 25 11500H	 AS2010305 25 12000H
 AS2010306 25 12300H	 AS2010307 25 11500H	 AS2010308 25 12000H
 AS2010309 25 11500H	 AS2010310 25 11500H	 AS2010401 25 11500H
 AS2010402 25 12300H	 AS2010405 25 11500H	 AS2010406 25 12000H
 AS2010407 25 11500H	 AS2010408 25 11500H	 AS2010409 25 11500H

FOGGERS INDIA P. LTD.

LOC HANDY FOGGING MACHINE

SPARE PARTS MASTER INFORMATION

 AS2010501 25 1152PM	 AS2010502 25 1200PM	 AS2010503 25 1150PM
 AS2010504 25 1150PM	 AS2010505 25 1200PM	 AS2010506 25 1030PM
 AS2010507 25 1150PM	 AS2010508 25 1150PM	 AS2010509 25 1150PM
 AS2010510 25 1150PM	 AS2010511 25 1200PM	 AS2010512 25 1150PM
 AS2010513 25 1200PM	 AS2010601 25 1150PM	 AS2010602 25 1150PM
 AS2010603 25 1200PM	 AS2010604 25 1150PM	 AS2010605 25 1150PM
 AS2010606 25 1150PM	 AS2010607 25 1150PM	 AS2010608 25 1150PM
 AS2010610 25 1150PM	 AS2010613 25 1150PM	 AS2010614 25 1201PM

FOGGERS INDIA P. LTD.

LOC HANDY FOGGING MACHINE

SPARE PARTS MASTER INFORMATION

 AS2010615 20 10/2004	 AS2010701 20 10/2004	 AS2010708 20 10/2004
 AS2010709 20 12/2004	 AS2010711 20 11/2004	 AS2010712 20 11/2004
 AS2010714 20 11/2004	 AS2010715 20 10/2004	 AS2010716 20 10/2004
 AS2010717 20 10/2004	 AS2010718 20 10/2004	 AS2010719 20 10/2004
 AS2010720 20 10/2004	 AS2010720 20 10/2004	 AS2010800 20 11/2004
	 AS2010801 20 10/2004	

