

BALWAN 4S

| | | | | |
|---|---|---|---|---|
|  |  |  |  |  |
| 46 BL4-E-46-Piston Assy | 47 BL4-E-47-Piston Ring | 48 BL4-E-48-Crankshaft Assy | 49 BL4-E-49-Ignition | 50 BL4-E-50-Fly Wheel |
|  |  |  |  |  |
| 51 BL4-E-51-Carurator | 52 BL4-E-52-Clutch | 53 BL4-E-53-Driving Set | 54 | 55 |
|  |  |  |  |  |
| 56 BL4-E-56-Air Cleaner | 57 BL4-E-57-Admiting Pipe | 58 BL4-E-58-Cylinder Head Cover | 59 BL4-E-59-Oil Dipstick | 60 BL4-E-60-Cam Gear Iron |
|  |  |  |  |  |
| 61 BL4-E-61-Exhaust Pipe | 62 BL4-E-62-Muffler | 63 BL4-E-63-Fan Blade | 64 BL4-E-64-Carburetor Plate | 65 BL4-E-65-Oil Baffle Plate |
|  |  |  |  |  |
| 66 BL4-E-66-Cam Gear Gasket | 67 | 68 BL4-E-68-Start Reel | 69 BL4-E-69-Oil Seal 15* 25*6 | 70 BL4-E-70-Oil Seal 12* 25*6 |
|  |  |  |  |  |
| 71 BL4-E-71-Gasket Full Set | 72 BL4-E-72-Rocker Arm Shaft | 73 BL4-E-73-Under The Rocker Shaft | 74 BL4-E-74-Rocker Arm | 75 BL4-E-75-Under The Rocker |
|  |  |  |  |  |
| 76 BL4-E-76-Valve Spring Seat | 77 BL4-E-77-Valve Spring | 78 BL4-E-78-Valve In & Ex | 79 BL4-E-79-Spark Plug | 80 |
|  |  |  |  |  |
| 81 BL4-E-81-Reed Valve + Plate | 82 BL4-E-82-New Starter | 83 BL4-E-83-New Cylinder Cover | 84 | 85 |